



- 1** Tools needed to setup the Belshaw Type F depositor.
- a. Box cutter
 - b. 5/16" wrench or socket
 - c. 7/16" wrench or socket
 - d. 5/32" allen wrench
 - e. Flat tip screwdriver



- 2** Check packaging for damage before opening.
- a. If damage is found contact shipping company.
 - b. If no damage is found continue.



- 3** Open the box and check the Type F for concealed damage.



- 4** Remove the column mounting kit or wall mounting kit and cylinder assembly and oil from the box if purchased.

See QR code:
QSG-0005 & QSG-0006
to install F column or wall kits.



QSG-0005



QSG-0006



- 5** Remove plunger and column arms from box, if purchased.



- 6** Remove upper foam packaging



- 7** Foam removed



- 8** Remove Type F



- 9** Place on mounting kit pin



- 10** Remove cardboard packaging



- 11** Remove center foam packaging



- 12** Remove hopper if purchased



- 13** Remove motor



- 14** Install motor
See QR-0001





15 Fill with oil
See QR-0002



16 Install hopper
onto cylinder



17 Push the hopper
tightly onto cylinder



18 Install plunger into
cylinder and hopper



19 Install hopper cylinder
and plunger onto Type F



20 Slide crown bearing into
top of type F frame



21 Close and tighten
cylinder clamp



22 Tighten crown
bearing clamp



QR code to Belshaw Type F
Cake Donut Depositor